
		High Pressure Laminate	Edgebanding			Door Manufacturers				Olon		3D Laminate												
			PVC							Timberline	Suede	Satin	Medina ‡	Timberline	Suede	Satin	Medina ‡	Dackor	SSI North America	LG	Omnova	Renolit (Alkor, Benecke & Cova)	Riken	Alfatherm
			Timberline	Suede	Satin																			
Code	Description	HPL	Canplast	DuraEdge	Teknaform	Cal-Door	Drees	Decore-Ative Special-ties	Northern Contours	Molding	Nexgen													
WF408	Haystack	FB4080			WFL7756 ‡	Vintage Oak Natural				STK ‡	STK ‡							Vintage Oak Natural 3.0074.001-1 520 00						
WF417	Icy Mherge	FB4170			WFM8040 ‡					STK ‡										Coming soon ‡				
WF208	Libretti	FB2080	56496	2830	WH5746 / WFH5746 ‡ / WJH5746	Wenge	Italian Wenge / Sculpted Wenge	Wenge		STK	STK	Italian Wenge	Sculpted Wenge LA/0103			508942		Oak Melinga Dark 9.0435.075-172300 ‡	R762					
WF392	Licorice Groovz	FB3920			WR7321					STK						526842								
WF368	Linear Ash	FB3680			WH6854 / WFH68554 ‡	Linear Ash	Portuna 2		Kona	STK ‡			Linear Ash HO/2401 H56 ML ‡					Portuna #2 9.3251.001-172300 ‡						
WF421	Loft Reclamation Maple	FB4210			WFM8044 ‡																			
WF396	Merapi	FB3960			WR7009 / WFR7009 ‡	Merapi			Royal Canyon				Merapi HO/2706 H56 BL ‡											
WF345	Milltown Oak	FB3450			WM6455 / WFM6455 ‡							Milltown Oak				518241								
WF296	Mochatini	FB2960	55492		WH5949 / WFH5949 ‡					STK ‡	STK ‡							Lausanne D 46619	R296					
WF299	Nirvana	FB2990	55495		WH5945 / WFH5945 ‡																			
WF406	Noce Como	FB4060	55496		WR5946																			
WF342	Noce Secchia	FB3420	55729		WR6452											513297								
WF301	Noce Vettore	FB3010	55497		WH5947																			
WF398	Pacaya	FB3980			WR7010 / WFR7010 ‡	Pacaya			King's Canyon				Pacaya HO/2704 H56 BL ‡											
AF200	Pewter Frost	FB2000	55730		PR2415																			
WF377	Pewter Pine	FB3770			WR7013 / WFR7013 ‡					STK ‡		Pewter Pine ‡												
WF344	Queenston Oak	FB3440			WM6464 / WFM6464 ‡	Queenston Oak	Oak Melinga Grey				STK	Queenston Oak ‡				518239		Oak Melinga Grey 9.0435.068-172300 ‡						

		High Pressure Laminate	Edgebanding			Door Manufacturers				Olon		3D Laminate												
			PVC							Timberline	Suede	Satin	Medina ‡	Timberline	Suede	Satin	Medina ‡	Dackor	SSI North America	LG	Omnova	Renolit (Alkor, Benecke & Cova)	Riken	Alfatherm
			Timberline	Suede	Satin																			
Code	Description	HPL	Canplast	DuraEdge	Teknaform	Cal-Door	Drees	Decore-Ative Special-ties	Northern Contours	Molding	Nexgen	Dackor	SSI North America	LG	Omnova	Renolit (Alkor, Benecke & Cova)	Riken	Alfatherm						
WF409	Ranch Gate	FB4090			WFL7757 ‡	Vinatge Oak Bleached				STK ‡	STK ‡					Vintage Oak Bleached 3.0074.002-1 520 00								
WF357	Sandalwood	FB3570			WM6730 / WFM6730 ‡	Driftwood 3			Fisherman's Wharf							Driftwood #3 9.4218.003-172300 ‡								
WF203	Seria	FB2030	55471		WR5742 / WFR5742 ‡					STK				510070										
AF209	Shadow Frost	FB2090			PR2299																			
SF230	Sienna	FB4300			ST9211			Sienna	Forge	STK								NL7446						
SF241	Sienna Accentz					Sienna							Sienna 75/4203 A16 MI											
WF122	Silken Maple	FB1220	55466		WM5557											Crystal PF 47729								
AF210	Silver Frost	FB2100	86151		PM2561	Brushed Steel	Brushed Steel	Brushed Aluminum					Brushed Steel ME/0403 S20 BL	KA863 M1	509988	Brushed Aluminum 02.08.76.00 0017-822500								
WF420	Slate Mherge	FB4200			WFM8043 ‡					STK ‡								Coming soon ‡						
SF239	Storm	FB2390																						
WF397	Stromboli	FB3970			WR7011 / WFR7011 ‡	Stromboli			Grand Canyon	STK ‡			Stromboli HO/2705 H56 BL ‡											
WF422	Studio Reclamation Maple	FB4220			WFM8045 ‡																			
WF310	Talas Cherry	FB3100	55498		WM6316	Roman Walnut	Talas Cherry			STK			Talas Cherry KB/0806 HO1 MI											
WF391	Tobacco	FB3910			WR7320					STK				526840										
SF231	Umbra	FB4310			ST9212			Umbra	Umber	STK								NL7453						
SF242	Umbra Accentz					Umbra							Umbra 75/5100 A16 MI											

		High Pressure Laminate	Edgebanding			Door Manufacturers				Olon		3D Laminate												
			PVC							Timberline	Suede	Satin □	Medina ‡	Timberline	Suede	Satin □	Medina ‡	Dackor	SSI North America	LG	Omnova	Renolit (Alkor, Benecke & Cova)	Riken	Alfatherm
			Timberline	Suede	Satin □																			
Code	Description	HPL	Canplast	DuraEdge	Teknaform	Cal-Door	Drees	Decore-Ative Special-ties	Northern Contours	Molding	Nexgen													
WF294	Vanilla Stix	FB2940	55490		WR5942 / WFR5942 ‡					STK ‡	STK ‡								R294					
WF202	Verismo	FB2020	55470		WR5741 / WFR5741 ‡	Verismo				STK ‡	STK ‡			MT64003	509994									
WF263	Walnut Amati	FB2630	86167		WR5233	Dark Italian	Coco Noche	Dark Italian Walnut	Amati Walnut			Italian Walnut Amati						Amati PC 44576						
WF407	Weathered Vane	FB4070			WFL7755 ‡	Vintage Oak Tweedy				STK ‡	STK ‡							Vintage Oak Dark S3.0074.00 6-1 200 00						
WF226	Zambukka	FB2260	55546	4250	WR6315 / WFR6315 ‡					STK ‡	STK ‡							Lausanne E 46620						
WF227	Zhu	FB2270	55499		WR5835		Bamboo		X				Island Bamboo HO/1701 A07-Bl											